



P-CTC

Portable Cross The Counter hearing loop system

Features

- Easy to use
- No installation required
- Simple neat solution – no trailing wires
- Neat and compact
- Fully portable to be used in multiple locations
- Powered by a rechargeable battery

Common Applications

- Interview areas
- Reception desks
- Offices
- Small meeting rooms
- Home visits
- Libraries
- Bank Offices
- Health Centres

No installation, no set up, always ready to be used!

Providing versatile desktop induction loop assistance for hearing aid wearers, the portable induction loop is powered by a rechargeable battery and is always ready for immediate use if charged. No installation works are required.

The micro-processor controlled Portable Induction Loop features automatic gain control and noise gating to improve reception of speech and automatic standby mode to conserve battery life.

The Portable Cross-the-counter hearing Loop can be used on a one-to-one basis or in meeting room locations. The electro-magnetic field extends to a maximum of 1.2m radius from the unit.

Available with a handy wall mounted transparent shelf.

Portable Cross The Counter hearing loop system



Product overview

Height	250mm
Width	275mm
Depth	110mm
Weight	800g
Power	Rechargeable 12V internal battery
Battery life	About 4 hours use (\leq 24 Hours stand-by)
Microphone	Built-in electret mic on the back side
Coverage area	\leq 1.2m
External microphone connector	3.5mm jack plug socket
Power adaptor connection	(18V) 2.1 mm jack plug socket (EU power plug only)

Product description

Part No

202070	P-CTC, Portable Cross the counter hearing loop, loop and mic unit
202070A	P-CTC and shelf unit kit
202071	Shelf unit for P-CTC

Accessories – Part No and description

241501	13T, Electret boundary mic (Conference mic), 3.5mm plug, \varnothing 80xH16mm, 3m cable
--------	---



For additional information, please refer to User Guide/Installation Guide and CE Certificate which can be downloaded from www.univox.eu. If required, spare part list or other technical documents can be ordered at support@edin.se.